


## TWIST-VALVE BONNET ASSEMBLY

- Allows you to turn the air on in degrees
- Passes more air than the conventional air-valve



Made in U.S.A.



## TWIST-VALVE BONNET ASSEMBLY

The new Twist Valve is a unique adjustable air valve. It directly replaces the standard push-pull valve. The old style push-pull valve is either on or off. The new twist valve allows you to turn the air on in degrees. Because of its flow-through design, when the twist valve is fully on, it passes more air than the conventional air-valve.

The twist valve will fit our S-3, S-5 and S-15 torches.



Part#	Description
-------	-------------

10167	Twist-Valve Stem
10064	O-Ring
10165	Flat Washer
10166	Tension Spring
10168	Solid Bonnet
10160	Twist-Valve Bonnet Assembly

To add the Twist-Valve assembly to your torch. Insert the parts starting with the Stem first. Do not over tighten the Bonnet as it will lock the Twist-Valve Stem.

**C.H. Symington & Co., Inc.**

**Main Office:** 6063 Frantz Road, Ste.103, Dublin, Ohio 43017

**Phone:** (614) 766-2602 **Web site:** [www.chsymington.com](http://www.chsymington.com)

**FAX:** (614) 766-2715 **E-Mail:** [symex@aol.com](mailto:symex@aol.com)

**Warehouse/Shop:** 10 Point Street, Carroll, Ohio 43112